

How to Distribute the Irish Saorview Channels

Outside


Aerial Installed using the Supplied Wall Bracket

* Possible (but not ideal) to Mount the Aerial in your attic

Attic Space



Amp is Mains Powered



Aerial Input (Coax Connector)

Connects to the ANT IN (or RF IN) on the back of Box



Inside Rooms

Run the included HDMI Cable to your TV



Tutorial & Assembly Video Guides Available for all Associated Components
You can Find the Videos on the Individual Product Pages