

How to Distribute Irish & UK Channels Throughout the House

Outside

Aerial Installed using the Supplied Wall Bracket

* Possible (but not ideal) to Mount the Aerial in your attic

Satellite Dish Comes with it's own Wall Bracket

LNB Output (F Connector)

Quad LNB

Can feed up to 4 rooms

1234

Attic Space



Amp is Mains Powered

4 Way Distribution Amplifier

Aerial Input (Coax Connector)

To Room 1,2,3,4

1

2

3

4

Connects to the ANT IN (or RF IN) on the back of Box

LNB Feed Runs Directly to EACH Combo Box

TV Rooms

Run the included HDMI Cable to your TV



Tutorial & Assembly Video Guides Available for all Associated Components
You can Find the Videos on the Individual Product Pages