How to Distribute UK Satellite Channels

Outside

Satellite Dish Comes with it's own Wall Bracket



Can feed up to 4 rooms 1234

Attic Space

Use F Connectors & Joiners to
connect to existing TV Cables in wall

If cable is not already present,
just run cable directly from LNB

To LNB IN

Room 1

Room 3

Room 2

Room 4

TV Rooms

Run the included HDMI or Scart Cable to your TV

Tutorial & Assembly Video Guides Available for all Associated Components
You can Find the Videos on the Individual Product Pages